



Slip Cover Dining Chair
Installation & Washing Instructions



www.1825interiors.com.au

Slip cover assembly

Avoid opening the package with a knife as it may damage the slip cover.
Keep your installation and washing instructions in a safe place for future reference.

1. Place the cover over the chair back first.
 2. Carefully pull it down over the seat and legs.
 3. Smooth the cover until flat.
-

Warning

1. The maximum weight limit for this dining chair is 150 kg. Please DO NOT exceed the weight limit.



-
2. When moving the chair away from the dining table, lift it - DO NOT drag it.
-

Fabric specifications

Fabric	100% Polyester
Classified as	Heavy Domestic Use
Flame Retardant	EN1021/1 and EN 1021/2 – European standards, BS 5852 UK Standards, Ca Tb 117-2013 USA Standard
Low seam slippage	Warp & Shrinkage 1–5 mm accepted
Low pilling	Pilling may occur depending on reactions with other fabrics (refer to Important Points on page 7)
This fabric is a classic flat woven textile with a semblance of linen. Excellent functional performance with an understated comfortable look.	



texstyle.dk

Caledonia Dining Chair Warranty

- Dining chair – 1 year.
- Fabric – 1 year. The fabric will be tested to ensure the customer followed the washing instructions correctly.
- All warranty service calls or transport for inspection of a manufacturing fault is at the customer's expense.

Guardsman Fabric Protection

- Fabric protection is an optional extra for peace of mind. Warranties cover the Caledonia dining chair with washable slip cover for 5 years if washing instructions are adhered to correctly and Guardsman's recommendations are followed.
- Refer to <https://www.guardsmanaustralia.com> for further details.

Cleaning Guide

Washing Instructions

- If the covers are too bulky for your washing machine, take them to your local laundromat for professional washing.
 - Professional dry cleaning is possible but some colour variation may occur if the cushions are cleaned separately from the main covers.
 - Wash below 30 degrees. Do not use a washing agent that contains optic bleach. We recommend Earth Choice 3X Ultra Concentrate Laundry Liquid, Eco Store Laundry Powder or Omo Expert Mixed Colours & Blacks Liquid.
 - Wash separately.
 - Do not squeeze or wring by hand.
 - Do not tumble dry.
 - Air dry in the shade.
 - Place the cover on the chair frame when they are still slightly moist to minimise shrinkage and allow to dry completely before use.
-

Spot Cleaning

- Treat spills and stains as soon as possible.
- Test on hidden area to ensure fabric and colour are not removed.
- Gently scrape any soils or mop any liquids from the surface of the fabric.
- Use of soap or detergent with water should be approached with caution since overzealous rinsing to remove soap residue may result in over-wetting, water marking and possible wetting of substructure (this may create other stains or damage products).

For Non-Oil-Based Stains: Use warm water and non-toilet soaps which do not contain optical brighteners such as Velvet soap, Lux Flakes and Softly. Mix a small amount of soap and warm water solution and apply to the stain, rubbing gently. Blot dry with a clean white cloth. Apply cool water - preferably filtered or distilled - and blot dry again. Working from the outside of the stain with a hairdryer, dry quickly to prevent rings from forming. It is generally preferable to clean whole panels of fabric in this way rather than trying to spot clean specific areas.

For Oil-Based Stains: Following the same basic guidelines as above, apply a proprietary brand solvent based cleaner and try to clean generally in panels rather than spot cleaning specific areas.

User Recommendation

We hope you enjoy your new furniture. Correct maintenance will increase its longevity and keep it looking in tip-top condition for longer.

Follow these simple tips.

1. Furniture should be assembled according to our Assembly Guides.
 2. Store furniture on robust flooring in dry, well-ventilated rooms.
 3. Keep furniture at least 30 cm away from radiators, air-conditioners and extreme temperatures.
 4. Protect your furniture from direct sunlight which can discolour fabric.
 5. Don't jump on or apply sudden force to the furniture as it may damage the frame or suspension.
 6. When repositioning the furniture, lift it – DO NOT drag it.
 7. Your pet's claws and teeth can damage furniture.
 8. Avoid using cleaning products containing harsh chemicals or oil dissolving solvents.
 9. Vacuum crevices of furniture on a low suction when needed.
-

Important points

1. Moisture

Our products are made using wood and other materials that can be sensitive to moisture. We recommend keeping furniture in an environment with 45-60% relative moisture and at 10-25°C.

2. Sunlight

After time the fabric colour will change slightly, which is a natural effect. To reduce this process, keep furniture out of direct sunlight.

3. Wear and Tear

Using furniture for a long time will result in slight material changes.

4. Pilling

Through regular use, the surface of natural fibre fabric can twist and form tiny balls – this is known as pilling. It is an inherent feature of this particular type of fabric and can be caused by environmental factors such as humidity or friction between two fabrics. It can be easily removed with a depiller and should disappear after 3-4 applications.

5. Storage

Ensure furniture stands on an even surface. This ensures stability and will prevent creaking or damage to the piece.

6. Felt Pads

We recommend attaching felt pads to the bottom of furniture legs. This prevents squeaking and protects your floor from scratches.

7. Fabric Variation

There may be slight variations between fabrics. The dyeing process means there is not an absolute guarantee that your sofa fabric will perfectly match the sample fabric.

8. Clothing and Accessories

Jeans and other dark clothing may leave stains or marks on furniture. Take extra care when wearing clothing that is new or not pre-washed. Also be careful wearing clothes with sharp decorative elements, as it may damage the fabric.

9. Softness

Furniture tends to soften after the first few months of use. This is a normal process. Parts of the furniture that are sat on more frequently will become softer than others.



www.1825interiors.com.au